





AIRTRONIC AIR HEATERS

TECHNICAL DATA



HOW THE AIRTRONIC HEATER WORKS

The Airtronic line of heaters operate like forced air furnaces. The Airtronic heats and propels air into the vehicle compartment via the vehicle's own venting system. These heaters cycle quietly through four levels to maintain a desired temperature range without idling.



AIR HEATERS		AIRTRONIC D5	D8LC
Heat Output (kW/BTU)	Boost	5.5 / 18800	4.0 / 13650
	High	4.8 / 16400	3.0 / 10200
	Medium	2.7 / 9200	2.0 / 6800
	Low	1.2 / 4100	0.9 / 3400
Fuel Consumption (l/hr / US gal/hr)	Diesel 1/2	0.66 / 0.17	0.51 / 0.13
	Boost	0.58 / 0.15	0.38 / 0.10
	High	0.34 / 0.09	0.25 / 0.07
	Medium	0.15 / 0.04	0.11 / 0.03
Electrical Consumption (amps) (12V shown, 12V or 24V available)	Boost	7.1	3.3
	High	6.7	2.0
	Medium	2.5	1.1
	Low	1.3	0.6
Weight (kg/lbs)		9.3 / 20.0	4.5 / 9.9